ALFA ROMEO



1750 BERLINA

1971 MODEL YEAR

INIEZIONE

OWNER'S MANUAL

U.S. DOT CONSUMER INFORMATION that applies to this vehicle can be found on Pages 18 and 19

Alfawiki nl

IMPORTANT NOTE

The fuel injection system for the 1750 model has been designed not only to attain high performance and low fuel consumption but also to keep the exhaust emissions below the levels permitted by U.S.A. regulations.

The low exhaust emission levels have therefore been obtained by improving the distribution and the combustion. No devices to burn the unburned gases downstream of the exhaust valves are required. Of course, even with the fuel injection system fitted to the Alfa 1750, the exhaust emissions will not continue to meet U.S. specification unless the owner himself provides to have the prescribed servicing regularly carried out by authorized Alfa Romeo Dealers and provided that, when remedying troubles or performing any maintenance work on the engine or fuel feed system, the factory prescribed procedures are strictly followed.

Keep a record of the symbol stamped on the key handle.

lanition and antitheft device kev

SYMBOL



Key to driver's and passenger's door, glove compartment, trunk lid

SYMBOL



When ordering duplicate keys, please quote the symbol.

Alfawiki.nl



The operation and maintenance instructions contained in this manual, particularly as far as the efficiency of the fuel injection system is concerned.

MUST BE CAREFULLY OBSERVED

by every owner who desires to get the best from his vehicle and to ensure a long life for every component.

Owners are recommended, in their own interest, to entrust all maintenance and repair work to an authorized Alfa Romeo Dealer as such Dealers are equipped with the proper tools and staffed by specially trained mechanics.

Owners are reminded that Alfa Romeo cannot be responsible for any errors made by unauthorized service stations or for any damage resulting from the use of nongenuine spare parts and/or lubricants other than those indicated.

Direzione Assistenza

The data relating to weights, consumptions and speeds are approximate only; Alfa Romeo reserves the right to change without notice any features and data given in this manual.

Alfawiki.nl



Alfa Romeo take steps to ensure the optimum performance of their cars by providing Owners with special services during the entire life of their vehicles.

The **Service Coupon Book,** supplied with every new vehicle, bears the conditions that govern the provision of Alfa Romeo Services and the replacement of damaged parts during the period covered by the warranty.

Every Owner of an Alfa Romeo motorcar is supplied with two coupons covering certain free maintenance during the warranty period, and he must use these coupons on completion of the mileage as stated thereon.

The labor cost of the maintenance work listed on the coupons is free, but the lubricants and the filtering elements used are to Owner's account. Any work not covered by free coupons but found necessary during the inspection will be subject to the General Terms of Warranty. The coupons should be used whenever possible at the garage of the

Dealer that sold the Afrowik duling normal working hours.



The Dealer warrants the products of the Factory for 6 months from the date of delivery to the Owner; the warranty does not cover tires and non-essential accessories if made by third parties, nor does it cover spare parts.

The warranty covers the free repair of, or free supply and replacement of, any parts found to be unserviceable **because of an acknowledged defect of materials;** defects will be acknowledged after prior investigation of them and of their causes exclusively by the manufacturer's workshops or by workshops authorized by the manufacturer, and at the said workshops.

Should the Purchaser insist on the services of an Alfa Romeo technician for the purpose of inspecting faulty or allegedly faulty parts, the expenses of such a technician will be the responsibility of the Purchaser.

Delays, if any, shall not entitle the Purchaser to receive compensation for damages, nor to any extension of his rights under the warranty.

The warranty shall lapse automatically:

if the products are used otherwise than in accordance with the manufacturer's instructions:

if they are modified, repaired or disassembled elsewhere than in the manufacturer's workshops or workshops authorized by the manufacturer;

The Purchaser shall not be entitled, in any of the cases stipulated by this article, to claim cancellation of the Contract or compensation for damages.

Contents

- 2 Service Coupon Book
- 3 Warranty
- 5 Identification

Specification:

- 6 Berlina
- 8 GT Veloce
- 10 Spider Veloce

Controls and instruments:

- 12 Berlina
- 14 GT Veloce
- 16 Spider Veloce

Consumer information

- 18 Berlina
- 20 GT Veloce
- 22 Spider Veloce
- 24 Breaking in

HOW TO USE YOUR CAR

- 25 Starting the engine antitheft
- 26 Starting the engine (from cold, when hot)
- 27 Light switch
- 29 Precautions (while driving & parking)
- 30 Temperature setting
- 31 Winter precautions

Ventilation, demisting and heating:

- 32 Berlina
- 36 GT Veloce
- 39 Spider Veloce
- 40 Interior: Berlina
- 45 Safety belts
- 46 Interior: GT Veloce
- 50 Interior: Spider Veloce
- 54 Folding top: Spider Veloce
- 56 Wheel removal
- 57 Towing

LUBRICATION

- 58 Regular lubrication schedule
- 59 Regular lubrication and lubricants
- 60 Engine
- 61 Oil pump and filter

MAINTENANCE

- 62 Regular maintenance schedule
- 63 Regular maintenance

ENGINE MAINTENANCE

- 64 Tightening torque specifications
- 65 Valve timing
- 67 Fuel injection
- 68 Injection system diagram
- 71 Air cleaner
- 71 Fuel filters
- 73 Trouble shooting
- 74 Ignition
- 78 Cooling system

CHASSIS MAINTENANCE

- 81 Clutch
- 82 Transmission
- 83 Drive shaft
- 84 Rear axle
- 85 Front suspension
- 86 Rear suspension
- 87 Steering gear and linkage
- 88 Front wheels (toe in)
- 89 Front wheels (camber)
- 90 Brakes
- 99 Wheel balancing
- 100 Tire inflation pressures
- 101 Tire changing over

102 BODY MAINTENANCE


103 LAYING THE CAR UP PRECAUTIONS

ELECTRICAL SYSTEM

- 104 Battery
- 105 Alternator, starter
- 106 Replacing a lamp or bulb
- 109 Headlamp beam setting

Alfawiki.td1 Wiring diagrams

Alfa Romeo FFFI





Chassis no.

on firewall

2 on windshield post

- 3 Car model no. on firewall
- 4 Engine no. on crankcase R.H. side
- 3 Finish plate (paint type & make) on trunk lid

On contacting the Factory or a Member of our Service Organization please state: car model no., chassis no., registration date, distance covered and car's purchase data.

Alfawiki.nl



Specification

Engine	Bore and stroke	in line 8.5 mm 779 cc. 35 SAE
Chassis		36.5 ft 4 SR 14 442 lbs
Fuel, oil and coolant	Cooling system: Alfa Romeo coolant mixture abt. 2.1 gals 2. Fuel	gals


PERFORMANCE with 41:9 final drive

AFTER BREAKING IN	The
mph.	be
28	resi
46	3
68	The
91	use
112	1 0011
30 Alfaw	iki nl
	BREAKING IN mph. 28 46 68 91 112

The maximum speeds indicated should not be exceeded or mechanical damage may result.

The performances given are related to the use of the vehicle in average travelling conditions.

1750 BERLINA





Specification

Engine	Number and layout of cylinders 4 in line Bore and stroke 80 x 88.5 mm	
	BHP @ 5500 rpm	
		_
Chassis	Turning circle	
	Designated seating capacity 2	
	Tires (Kleber Colombes V10 GT - Michelin XAS -	
	Pirelli Cinturato HR)	
	Curb weight	
	IMP. U.S.A.	
Fuel, oil	Cooling system:	
and coolant	Alfa Romeo coolant mixture abt. 2.1 gals 2.5 gals	
	Fuel	
	For best engine performance the use of premium grade fuel is advised.	
	Fuel reserve abt. 1.3-1.5 gals 1.6-1.8 gals	
	Engine (pan and filter)	
	when full★ » 5.95 qts 7.1 qts	
	danger level » 3.95 qts 4.75 qts	
	Transmission	
	Differential	
	Steering box	
	★ This quantity is that needed for regular	
	changing. The total amount of oil in the circuit (pan, filter and passages) is abt. 6.5 qts 7.8 qts	

PERFORMANCE


with 41:9 final drive

GEAR	AFTER BREAKING IN	The
	mph.	be
1st	29	res
2nd	48	
3rd	71	The
4th	96	use
5th	120	
Rev.	32 Alfaw	ki.nl

The maximum speeds indicated should not be exceeded or mechanical damage may result.

The performances given are related to the use of the vehicle in average travelling conditions.

1750 GT VELOCE®





Specification

Engine	Bore and stro Total displace	ayout of cylinders		8	30 x 88.5 1779	line 5 mm 9 cc. SAE	
Chassis	Tires (Kleber	eating capacity			165 H	4.5 ft 2 HR 14 2 Ibs	
Fuel, oil and coolant	Fuel For best engine grade fuel is a Fuel reserve Engi OIL Tran Diffe Steel	oolant mixture abt	10.1 1.3-1.5 5.95 3.95 3.2 2.5 .7	gals gals gals qts	1.6-1.8 7.1 4.75 3.8 3.0 .8	gals gals gals	

PERFORMANCE with 41:9


with 41:9 final drive


GEAR	AFTER BREAKING IN
	mph.
1st	29
2nd	48
3rd	71
4th	96
5th	120
Rev.	32 Alfaw

The maximum speeds indicated should not be exceeded or mechanical damage may result.

The performances given are related to the use of the vehicle in average travelling conditions.

1750 SPIDER VELOCE®





To engage the REVERSE merely shift the lever from neutral (F) as shown.





Controls and instruments




Instruments

1	Heater	blower	warning	light
---	--------	--------	---------	-------

- 2 Alternator warning light
- Tachometer
- Main odometer
- Tripometer
- Parking light warning
- Speedometer
- Headlamp high beam warning light
- Fuel reserve warning light
- 10 Fuel level indicator
- Electric clock
- 13 Coolant temperature indicator
- 14 Oil pressure gage
- Warning light for direction indicators
- Low oil pressure warning light. See page 61
- Service brake warning light (push-to-17 test type). See page 91
- Parking brake warning light 21
- Low fuel pressure warning light. See pages 25 and 68
- Emergency flasher push button switch with built in warning light
- 28 Fusebox
- Additional fuse holder
- Clock reset 12
- Ignition switch, antitheft & buzzer 18
- 19 Tripometer reset
- 22 Horn
- 24 Direction indicator switch
- Electrically-heated rear window switch
- 27 Headlamp, dimmer and flashing switch
- 30 Hood release
- Hand throttle 31
- Windshield washer: when the control is pressed the windshield wiper also comes into action
- 34 Clutch
- 35 Brake
- 36 Accelerator
- 37 Heating, ventilating and demisting
- Gearshift lever 39
- 40 Blower switch (two-speed)
- Fog lamp switch 41
- Windshield wiper switch (two-speed)
- Hand brake (for emergency and parking)
- Windshield demisting outlet 20
- Ventilating air outlet 33
- 38 Speaker compartment
- Ash tray (removable) 43
- Cigarette lighter: insert a cigarette then push the knob in: this brings into operation an electric element which lights the cigarette.
- 45 Utility recess
- Gloválfovníkartíment 47
- 48 Shelf

Controls

Luxury fittings



To engage the REVERSE merely shift the lever from neutral (F) as shown.

Alfawiki.nl

Controls and instruments



Instruments


- 1 Tachometer
- 2 Low oil pressure warning light. page 61
- Oil pressure gage
- 4 Main odometer
- Tripometer
- Speedometer
- Alternator warning light
- Heater blower warning light
- 9 Fuel reserve warning light
- 10 Fuel level indicator
- Coolant temperature indicator 11
- 12 Low fuel pressure warning light. See pages 25 and 68
- 13 Parking brake warning light
- 14 Emergency flasher push button switch
- 15 Headlamp high beam warning light
- 16 Parking light warning
- Warning light for direction indicators 17
- 20 Service brake warning light (push-totest type). See page 91
- Additional fuse holder
- 32 Fusebox
- Ignition switch, antitheft & buzzer
- 21 Tripometer reset
- 22 Electrically-heated rear window switch
- 24 Horn
- 25 Direction indicator switch
- Headlamp, dimmer & flashing switch
- 27 Hood release
- 28 Hand throttle
- Windshield washer: when the control is pressed the windshield wiper also comes into action
- 33 Clutch
- 34 Brake
- 35 Accelerator
- 38 Gearshift lever
- 40 Blower switch (two speed)
- 41 Fog lamp switch
- 42 Windshield wiper switch (two speed)
- Hand brake (for emergency and parking)
- Cigarette lighter: insert a cigarette, then push the knob in: this brings into operation an electric element which lights the cigarette
- 23 Air outlets (adjustable)
- 31 Pocket for documents & literature
- 36 Heating, ventilating and demisting
- 37 Glove compartment
- 39 Speaker compartment
- 43
- Ash tray (removable) Pock**ell awis by**on Book 45



45

Controls

Luxury fittings




To engage the REVERSE merely shift the lever from neutral (F) as shown.


Controls and instruments











- Tachometer
- Alternator warning light Main odometer
- Speedometer
- 5 Tripometer
- Heater blower warning light
 - Fuel reserve warning light
- Fuel level indicator
- Oil pressure gage
- 10 Coolant temperature indicator
- Direction indicator warning light
- Low fuel pressure warning light. See pages 25 and 68
- Warning light for low oil pressure (see page 61) and parking brake
- 23 Additional fuse holder
- 24 Fusebox
- 31 Headlamp high beam warning light
- Parking light warning
- Service brake warning light (push-totest type). See page 91
- Emergency flasher push button switch with built in warning light
- 12 Horn
- 18 Headlamp, dimmer & flashing switch
- Direction indicator switch
- 20 Hood release
- 22 Windshield washer: when the control is pressed the windshield wiper also comes into action
- 25 Ignition switch, antitheft & buzzer
- 26 Tripometer reset
- 27 Clutch
- 28 Brake
- 29 Accelerator
- 35 Gearshift lever
- Blower switch (two-speed)
- Dashboard light switch (acts only when parking lights are on)
- Windshield wiper switch (two-speed) 38
- Hand throttle (pull and rotate clockwise)
- Hand brake (for emergency and parking)
- 11 Ventilating air outlet
- Windshield demisting outlet 14
- 17 Glove compartment (with interior light-
- 21 Side outlet lever
- 30 Heating, ventilating and demisting
 - Ash tray (removable)
- Cigarette lighter: insert a cigarette, then push the knob in: this brings into operation an electric element which lights the cigarette
 Pocket few buryon Book

Instruments

Controls

Luxury fittings



CONSUMER INFORMATION Acceleration and passing ability

DESCRIPTION OF VEHICLES TO WHICH THIS TABLE APPLIES: 1750 BERLINA

This figure indicates passing times and distances that can be met or exceeded by the vehicles to which it applies, in the situations diagrammed below.

The low-speed pass assumes an initial speed of 20 mph and a limiting speed of 35 mph. The high-speed pass assumes an initial speed of 50 mph and a limiting speed of 80 mph.


Notice: the information presented represents results obtainable by skilled drivers under controlled road and vehicle conditions, and the information may not be correct under other conditions.

Summary table: Low-speed pass 395 feet; 8.4 seconds High-speed pass 1165 feet; 12.3 seconds


LOW SPEED

Initial speed: 20 mph

Limiting speed: 35 mph



HIGH SPEED



55' TrAPfawiki.nl



CONSUMER INFORMATION

Acceleration and passing ability

Vehicle stopping distance

Tire reserve load

1750 BERLINA

Alfawiki.nl


CONSUMER INFORMATION Vehicle stopping distance

CONSUMER INFORMATION Tire reserve load

DESCRIPTION OF VEHICLES TO WHICH THIS TABLE APPLIES: 1750 BERLINA

This figure indicates braking performance that can be met or exceeded by the vehicles to which it applies, without locking the wheels, under different conditions of loading and with partial failures of the braking system.

The information presented represents results obtainable by skilled drivers under controlled road and vehicle conditions, and the information may not be correct under other conditions.



Alfawiki.nl

DESCRIPTION OF VEHICLES TO WHICH THIS TABLE APPLIES: 1750 BERLINA

This tables lists the Tire Size Designations recommended by the manufacturer for use on the vehicles to which it applies, with the recommended inflation pressure for maximum loading and the tire reserve load percentage for each of the tires listed. The tire reserve load percentage indicated is met or exceeded by each vehicle to which the table applies.

Recommended ti size designations		165 SR 14 Pirelli	165 SR 14 Michelin	165 SR 14 Kléber
Recommended cold inflation pressure for	Front	22	26	24
maximum loaded vehi- cle weight (psi)	Rear	23	26	29
Tire reserve loa centage (1)	d per-	8.6	14.5	15.1

(1) The difference expressed as a percentage of tire load rating, between (a) the load rating of a tire at the vehicle manufacturer's recommended inflation pressure at the maximum loaded vehicle weight and (b) the load imposed upon the tire by the vehicle at that condition.

WARNING - Failure to maintain the recommended tire inflation pressure or increase tire pressure as recommended when operating at maximum loaded vehicle weight, or loading the vehicle beyond the capacities specified on the tire placard affixed to the vehicle, may result in unsafe operating conditions due to premature tire failure, unfavorable handling characteristics, and excessive tire wear. The tire reserve load percentage is a measure of tire capacity not of vehicle capacity. Loading beyond the specified vehicle capacity may result in failure of other vehicle components.



CONSUMER INFORMATION Acceleration and passing ability

DESCRIPTION OF VEHICLES TO WHICH THIS TABLE APPLIES: 1750 G.T. VELOCE

This figure indicates passing times and distances that can be met or exceeded by the vehicles to which it applies, in the situations diagrammed below.

The low-speed pass assumes an initial speed of 20 mph and a limiting speed of 35 mph. The high-speed pass assumes an initial speed of 50 mph and a limiting speed of 80 mph.


Notice: the information presented represents results obtainable by skilled drivers under controlled road and vehicle conditions, and the information may not be correct under other conditions.

Summary table: Low-speed pass 390 feet; 8.2 seconds High-speed pass 1140 feet; 12.0 seconds

LOW SPEED

Initial speed: 20 mph

Limiting speed: 35 mph




55' Truck

HIGH SPEED

Initial speed: 50 mph

Limiting speed: 80 mph



55' Truck Alfawiki.nl



CONSUMER INFORMATION

Acceleration and passing ability

Vehicle stopping distance

Tire reserve load

1750 GT VELOCE®

Alfawiki.nl


CONSUMER INFORMATION Vehicle stopping distance

CONSUMER INFORMATION Tire reserve load

DESCRIPTION OF VEHICLES TO WHICH THIS TABLE APPLIES: 1750 G.T. VELOCE

This figure indicates braking performance that can be met or exceeded by the vehicles to which it applies, without locking the wheels, under different conditions of loading and with partial failures of the braking system.

The information presented represents results obtainable by skilled drivers under controlled road and vehicle conditions, and the information may not be correct under other conditions.



Alfawiki.nl

DESCRIPTION OF VEHICLES TO WHICH THIS TABLE APPLIES: 1750 G.T. VELOCE

This table lists the Tire Size Designations recommended by the manufacturer for use on the vehicles to which it applies, with the recommended inflation pressure for maximum loading and the tire reserve load percentage for each of the tires listed. The tire reserve load percentage indicated is met or exceeded by each vehicle to which the table applies.

Recommended tire size designations		165 HR 14 Pirelli	165 HR 14 Michelin	165 HR 14 Kléber
Recommended cold inflation pressure for	Front	24	20	24
maximum loaded vehi- cle weight (psi)	Rear	26	24	26
Tire reserve load percentage (1)		23	15.1	23

(1) The difference expressed as a percentage of tire load rating, between (a) the load rating of a tire at the vehicle manufacturer's recommended inflation pressure at the maximum loaded vehicle weight and (b) the load imposed upon the tire by the vehicle at that condition.

WARNING - Failure to maintain the recommended tire inflation pressure or increase tire pressure as recommended when operating at maximum loaded vehicle weight, or loading the vehicle beyond the capacities specified on the tire placard affixed to the vehicle, may result in unsafe operating conditions due to premature tire failure, unfavorable handling characteristics, and excessive tire wear. The tire reserve load percentage is a measure of tire capacity not of vehicle capacity. Loading beyond the specified vehicle capacity may result in failure of other vehicle components.



CONSUMER INFORMATION Acceleration and passing ability

DESCRIPTION OF VEHICLES TO WHICH THIS TABLE APPLIES: 1750 SPIDER VELOCE

This figure indicates passing times and distances that can be met or exceeded by the vehicles to which it applies, in the situations diagrammed below.

The low-speed pass assumes an initial speed of 20 mph and a limiting speed of 35 mph. The high-speed pass assumes an initial speed of 50 mph and a limiting speed of 80 mph.


Notice: the information presented represents results obtainable by skilled drivers under controlled road and vehicle conditions, and the information may not be correct under other conditions.

Summary table: Low-speed pass 380 feet; 8.0 seconds
High-speed pass 1110 feet; 11.5 seconds

LOW SPEED

Initial speed: 20 mph


Limiting speed: 35 mph



HIGH SPEED

Initial speed: 50 mph

Limiting speed: 80 mph



55' TruAlfawiki.nl



CONSUMER INFORMATION

Acceleration and passing ability Vehicle stopping distance Tire reserve load

1750 SPIDER VELOCE®


CONSUMER INFORMATION Vehicle stopping distance

CONSUMER INFORMATION Tire reserve load

DESCRIPTION OF VEHICLES TO WHICH THIS TABLE APPLIES: 1750 SPIDER VELOCE

This figure indicates braking performance that can be met or exceeded by the vehicles to which it applies, without locking the wheels, under different conditions of loading and with partial failures of the braking system.

The information presented represents results obtainable by skilled drivers under controlled road and vehicle conditions, and the information may not be correct under other conditions.



APPLIES: 1750 SPIDER VELOCE

This table lists the Tire Size Designations recommended by the manufacturer for use on the vehicles to which it applies, with the recommended inflation pressure for maximum loading and the tire reserve load percentage for each of the tires listed. The tire reserve load percentage indicated is met or exceeded by each vehicle to which the table applies.

Recommended ti		165 HR 14 Pirelli	165 HR 14 Michelin	165 HR 14 Kléber
Recommended cold inflation pressure for	Front	24	20	24
maximum loaded vehi- cle weight (psi)	Rear	26	24	26
Tire reserve load centage (1)	d per-	22.9	13.9	22.9

(1) The difference expressed as a percentage of tire load rating, between (a) the load rating of a tire at the vehicle manufacturer's recommended inflation pressure at the maximum loaded vehicle weight and (b) the load imposed upon the tire by the vehicle at that condition.

WARNING - Failure to maintain the recommended tire inflation pressure or increase tire pressure as recommended when operating at maximum loaded vehicle weight, or loading the vehicle beyond the capacities specified on the tire placard affixed to the vehicle, may result in unsafe operating conditions due to premature tire failure, unfavorable handling characteristics, and excessive tire wear. The tire reserve load percentage is a measure of tire capacity not of vehicle capacity. Loading beyond the specified vehicle capacity may result in failure of other vehicle components.

Alfawiki.nl

WARNING FOR THE FIRST 1900 miles

BREAKING IN

To allow the various parts of the car, particularly the engine, transmision and differential, to settle in gradually, a breaking in period necessary, during which maximum performance must not be demanded of the car.

RECOMMENDATIONS FOR THE FIRST 1900 MILES					
Mileage	Max r.p.m.	Cold starting: — before driving, run engine at approx. 1500 rpm for at least 3 minutes in summer and 5 minutes in winter.			
Up to 600	3500	While driving: — do not drive at max. recommended speeds for long periods;			
601 to 1900	4500	never fully depress the accelerator pedal; now and then release the accelerator pedal; avoid full and extended braking during the first 600 miles.			

DURING BREAKING-IN STRICTLY FOLLOW THE ABOVE DIRECTION

Note: The same recommendations apply also in the case of engine recondition involving replacement of cylinder barrels, pistons, piston rings and bearings.

FREE SERVICE COUPONS

COUPON A


COUPON B

At the first **500-750 mi**.

At the first 3000-3750 mi.
Alfawiki.nl

carry out the free servicing included coupons

How to use your car









Starting the engine

Make certain the gearshift lever is in neutral

Insert the key in the ignition switch and turn it clockwise to the MAR. position (ignition « on ») make sure the low fuel pressure warning light goes off after having flashed on.

Wait a few moments and then turn the ignition key further clockwise to AVV. to operate the starter.

As soon as the engine fires release the key.

If the engine fails to start, the key must be returned to $\ensuremath{\mathbf{STOP}}$ and the operation repeated.

For light location:

Berlina see 23 on page 13 GT Veloce see 12 on page 15 Spider Veloce see 15 on page 17

If the warning light does not flash on or stays on, this is an indication of failure of the indicating device or fuel feed system; therefore have them checked as soon as possible by an authorized Alfa Romeo Dealer. When opening driver's door, a suitable buzzer will alert you, if the key has been left in the ignition switch.

Note



Return the key counterclockwise to STOP. In such a position the ignition is « off ». The key can be withdrawn only in STOP position.

When the key is withdrawn, it is no longer possible to rotate the steering wheel.

Stopping the engine

By withdrawing the key (when in STOP position and steering wheel spokes balanced for straight ahead direction), the steering is blocked; to release the block easier slightly rotate the wheel in both directions. **Never withdraw the key before the car has come to a complete stop** as the «steering block» condition may occur.

MAR. = ignition; AVV. = starting; ST. = entire block.

Antitheft/steering block



How to use your car

From cold

Particularly when starting from cold in winter, it is advisable, in order to facilitate starting, to press the clutch pedal down fully.

Automatic devices, besides doing away with the conventional choke, facilitate the initial running of engine after a cold start, allow a faster warming up of the engine and improve driveability.

As an aid in starting from cold, depress, partially and progressively, the accelerator pedal. After a cold start and particularly when the room temperature is below freezing point, wait a fairly long time before getting away so as to warm up properly all engine parts and allow the oil to reach all points requiring lubrication.

Top performance must never be demanded of the car until coolant temperature is about 158 $^{\circ}\text{F}.$

When hot

When the engine is already hot or with very high room temperatures (above 77 °F) slowly depress the accelerator pedal to facilitate starting.

If the engine fails to start, look for the cause as follows:

- the battery charge may be too weak to rotate the starter sufficiently fast to start the engine;
- the ignition equipment may be defective (dirty plugs, oxidized contactbreaker points, wet or cracked distributor cap, damaged distributor or coil);
- the solenoid-actuated cold start device may fail to operate;
- electric circuits may be broken or fuses blown.


Do not accelerate the engine until it has warmed up, since when the engine is cold the oil cannot reach all points requiring lubrication.

Make sure the oil pressure shown by the gage is as prescribed and the oil pressure warning light goes off as soon as the engine speed exceeds idling.

Also make sure the alternator warning light goes off as engine exceed idling.

Check that the Aldor wile impressure warning light is off.

18



The switch lever may be in either of the two positions. The warning lights on the dashboard are out.

1 Lights off

Press on the knob irrespective of the position of the switch.

2 Flashing

Irrespective of the position of the lever, turn the knob to the first notch. The warning light on the dashboard will light up and flashing is still possible by pressing the knob.

Parking lights
and license
plate light

On Berlina and GT Veloce the dashboard lights will come on as well.

From position 3 turn the knob forward to the second notch.

If the lever is up, the dimmed lights come on (no flashing).

If on the other hand, it is down, the **beam lights** and the respective warning light come on (flashing possible).


The movement of the lever up and down allows the light to be dimmed or returned to beam.



The lights are extinguished by turning the lights are extinguished by the light are extinguished

Lights off

Emergency (road hazard) flashers



To operate the emergency flashers whare wired independently from the igniswitch, act on the toggle switch mounted the dashboard.



Fog lamps

The Berlina and GT Veloce are provided with fog lamps as standar equipment.

The lamps are controlled by the switch on the console when parking lights are on.

Alfawiki.nl

While driving

Take care not to run the engine beyond the maximum R.P.M. Check the oil pressure gage from time to time and stop the engine if the pressure with a hot engine and at maximum revolutions should fall below limits shown on page 61.

Check the low oil pressure warning light: if on, it is an indication of a trouble in the lubricating system: in this case, stop the car and have the lubricating system checked by an authorized Dealer.

However, it is possible for the warning light to come on when the

car is cornering: this may be caused by a low level of oil in the pan which can be easily remedied by topping up.

No trouble exists if the warning light comes on while the engine is idling, especially when hot.

Check that the low fuel pressure warning light on dashboard is off; when on, it means that the feed system is developing troubles; therefore, have it checked by your Dealer.

Do not drive at high speed until the oil in the engine, transmission and differential has warmed up properly.

When shifting gears, take care to depress the clutch pedal fully; this will ensure smooth operation and save synchronizers from excessive wear. Do not rest your foot on clutch pedal when not actually using it.

IMPORTANT NOTE

The fuel injection system allows the engine to be used in the widest RPM range; however, in gears higher than the second, the best performance and emission control as well, can only be attained by exceeding 2200 RPM.

Never leave the key in the MAR. position (ignition «on») to prevent battery discharge and coil damage. Apply the hand brake and, when parking the car uphill or downhill, shift into a low gear and steer the front wheels in such a direction as to cause the car should the parking brake disengage accidentally, to move toward the curb.

While parking


How to use your car

To keep a constant fuel/air ratio even when the room tempera varies as the seasons change, the average seasonal temperature c pensator lever, see figure, on the control unit shall be shifted to:

- mark N
- mark C
- mark **F**
- (normal) for room temperatures exceeding 59 °F.

 (cold) for temperatures between 59 °F and 32 °F.

(freezing) for temperatures below 32 °F.



WARNING

Never tamper with the seal on the reference screw of control unit input lever.

Alfawiki.nl

How to use your car

WINTER PRECAUTION

Cooling circuit

The Alfa Romeo coolant mixture gives full protection against freezing down to $-22\,^{\circ}\text{F}$.

In places where the temperature falls below — 22 °F, the antifreeze mixture can be made stronger by varying its concentration.

To this end, a certain amount of mixture should be drained off the circuit and replaced with the same quantity of Alfa Romeo antifreeze drawn from suitable containers available by Alfa Romeo Dealers.

The quantities of antifreeze to be added to radiator and reservoir depending on the lowest anticipated temperature are the following:

Temperature		omeo Coolant Mixtu uantity of Alfa Ron	
°F	Radiator	Reservoir	Total
— 24	400 cc.	100 cc.	500 cc.
— 33	800 cc.	200 cc.	1,000 cc.
— 38	1,200 cc.	300 cc.	1,500 cc.

It is recommended that this operation should be entrusted to an authorized Dealer.

Alfowiki.nl

2


How to use your car



- A Air inlets in engine hood
- B Air shutter
- C Electric blower
- D-E Water pipes
- F Windshield demisting slits
- G Air outlets into car
- H Ram air ventilation
- 1 Blower switch
- 2 Blower operation warning light
- 3 Temperature control3a Warm air
 - air 3c Fresh air


3b Warm & fresh

- 4 Air control
 - 4a Demisting 4b Demisting
 - ventilation heating
 - 4c Closed



VENTILATION DEMISTING AND HEATING





From A air enters thru:

- F for windshield demisting (warm and fresh air)
- G for ventilation and heating
- H for ventilation


Controls

The air admitted to the car thru B can be gradually heated by the movement of the lever 3 which operates the shutter B and the cock D.

- The movement of the lever 4 gradually regulates the flow of air thru the openings F and G.
- In order to produce a satisfactory flow of air into the car at low speeds, switch on the two-speed electric blower by means of switch 1. Warning light 2 indicates that this has been done.

Location of controls and air outlets






- ⇔ Fresh air
- Fresh or warm air

For a best ventilation, flow away slits are provided at rear window posts.

Ventilating outlets





LEVER DOWN « OPEN Jawiki.nl





LEVER UP « CLOSED »

VENTILATION DEMISTING AND HEATING

















Spot demisting






Windshield and front windows demisting

The illustrations show some examples of outlet positions. The outlets can be rotated by hand as desired.





Location of controls and air outlets

From A air enters thru:

- F for windshield demisting warm and fresh air)
- G for ventilation and heating

Controls

The air admitted to the car thru B can be gradually heated by the moderamik on the lever

- **3** which operates the shutte and the cock **D** (Ref. page
- The movement of the leve gradually regulates the flow air thru the openings F and
- In order to produce a satisficity flow of air into the carlow speeds, switch on two-speed electric blower means of switch 1. Warn light 2 indicates that this higher done.

VENTILATION DEMISTING AND HEATING





- Fresh or warm air

Opening the two quarter windows ensures proper ventilation of interior by enhancing the air flow away.

The opening of quarter windows can be regulated as desired by adjustable catches.



CLOSED



Alfawiki.nl

Quarter windows








demisting












The illustrations show some examples of outlet positions.

The outlets calforwikitaled by hand as desired.



From A air enters thru:

- F for windshield demisting (warm and fresh air). For maximum defrosting switch on the blower and close the shutter.
- E for ventilation and heating
- R ram ventilation

Controls

 The air admitted to the car can be heated by the movement of the lever **H** which operates the cock **D** (Ref. page 32).

- The movement of the lever G gradually regulates the flow of air thru the openings F and E.
- In order to produce a satisfactory flow of air into the car at low speeds, switch on the two-speed electric blower by means of switch N. Warning light P indicates that this has Alexwidene!

Location of controls and air outlets

INTERIOR



How to use your car

Sun visors

• The front seats are equipped with padded sun visors which ca be moved laterally.

Rearview mirror

 The rearview mirror, which disengages automatically in the event of a crash, has a day/night antiglare device.

Lighting


 Courtesy lighting is provided by two dome lights; the switches have three positions:

one in the center: lights always off two at the sides: lights always on or automatically operated whe

opening doors.

Ash trays

At the sides of the rear seats are two ash trays. They can be removed for emptying by pressing down the small central spring inside the ash tray.





 The positioning of the front seats is controlled by the lever 1 situated on the front edge of each seat: by freeing the lever the seat may be moved to the position desired.

The knobs ${\bf 2}$ at the outboard sides of the seats control the angle of the backrests.

• The seats are provided with vertically-adjustable head restraints 3.



Front seats

An arm rest with utility recess is provided between rear seats.

Alfawiki.nl

Rear seats

INTERIOR




How to use your car

Radio


Provision is made in the dashboard for the installation of the radio.

The location is:

- in the dashboard for the radio set
- in the console and on backshelf for the speakers.



TRUNK




To open the trunk lid, only rotate tkey in the lid lock.

The illumination of the trunk is effect by a light that operates automatica when the lid is raised and the parkilights are on.


HOOD



The hood opens opposite travel direction; to release the catch, pull the lever under the dashboard. The hood is held in open position by the suitable rod. 1. The illumination of the engine compartment is effected by a light fixed under It operates automatically the hood. when the hood is raised and the parking lights are on.



EMERGENCY RELEASE




To release the hood in an emergency, pull the ring shown by the arrow.

Alfawiki.nl

DOORS How to use your car





Front door


- 1 Handle for opening the door from insid
- 2 Safety lock button: for locking the do from inside, push the button in aff the door is shut. On rear doors t safety button can be pushed in for pr locking even if the door is open. Bo front doors have locks for closing from the outside.
- 3 Window regulator handle.
- 4 Vent window control.
- 5 Ash tray; it can be removed for emptyi by pressing down the small central spri inside the ash tray.




Rear door




The cars are equipped with safety belts of lap and lap-shoulder type as shown below.



BERLINA FRONT SEATS and GT VELOCE: LAP-SHOULDER



BERLINA REAR SEATS: LAP



SPIDER VELOCE: LAP

Note: on Berlina and GT Veloce rear lap-shoulder harness can be installed optionally.

Attachment provision:

- for BERLINA the third attachment is on the rear shelf;
- for GT VELOCE the three attachments are on the sheet metal behind the bench seat backrest and on the Alfrewiki. Wheelhouse and rear shelf.







INTERIOR



How to use your car

Sun visors

The front seats are equipped with padded sun visors which can be moved laterally.

Rearview mirror

The rearview mirror, which disengages automatically in the event of a crash, has a day/night antiglare device.

Lighting


Courtesy lighting is provided by two lights; the switches have three positions:

one in the center: lights always off

two at the sides: lights always on or automatically operated when opening doors.

Ash trays

At the sides of the rear seats are two ash trays. They can be removed for emptying by pressing down the small central spring inside the ash tray.



Alfawiki.nl


INTERIOR



• The positioning of the front seats is controlled by the lever 1 situated on the front edge of each seat: by freeing the lever the seat may be moved to the position desired. Seats

The knobs 2 at the outboard sides of the seats control the angle of the backrests. The levers 3 at the outboard sides of the seats allow to unlock the backrests for tipping forward.


The bucket type seats are provided with vertically-adjustable head restraints 4.



INTERIOR



How to use your car




Radio

Provision is made in the dashboard for the installation of the radio.

The location is:

- in the dashboard for the radio set
- in the console for the speakers.



Alfawiki.nl

DOORS


- 1 Lever to actuate and release the safety device (both doors). Both doors have locks for closing from the outside. To close, turn the key in the direction of travel (the key can be withdrawn only when it is vertical).
- 2 Window regulator handle.
- 3 Vent window control.



The hood opens opposite travel direction; to release the catch, pull the lever under the dashboard.

The hood is held in open position by the suitable rod 1.


The illumination of the engine compartment is effected by a light fixed under the hood. It operates automatically when the hood is raised and the parking lights are on.



TRUNK

To open, lift the lever situated on the door jamb on the driver's side.

The lock utilises the same key as the doors.



INTERIOR



How to use your car

Sun visors

Rearview mirror

The car is equipped with padded sun visors.


The rearview mirror, which disengages automatically in the event of a crash, has a day/night antiglare device.

Lighting

Internal lighting is provided by a lamp in the rearview mirror; the switch has two positions: light always on and courtesy light automatically operated when opening doors.

Hand grip

On the passenger's door there is a hand grip.



Alfawiki.nl

INTERIOR






Seats

- The positioning of the seats is controlled by the lever 1 situated on the front edge of each seat: by freeing the lever the seat may be moved to the position desired.
- The knobs 2 at the inboard sides of the seats control the angle of the backrests. The levers 3 at the outboard sides of the seats allow to unlock the backrests for tipping forward.


The bucket seats are provided with vertically-adjustable head restraints 4.

HARD TOP

Provision is made for the installation of the hard top.








Radio

Provision is made in the dashboard for the installation of the radio. To install it, remove the ornament from dashboard.

DOORS

- 1 Handle
- 2 Vent window control (with a safety catch)
- 3 Lever to actuate and release the safety device. Both doors can be locked from the outside.
- 4 Window regulator handle



Alfawiki.nl

HOOD




The hood opens opposite travel direction; to release the catch, pull the lever under the dashboard.

The illumination of the engine compartment is effected by a light fixed under the hood. It operates automatically when the hood is raised and the parking lights are on.


To open, lift the lever situated on the door jamb on the driver's side. The lock utilises the same key as the doors.

Lighting of the trunk is provided by a suitable lamp.




TRUNK










Folding the top

Lower the side windows.
Release the toggle clamps securing the top to the windshield bow.



Push the top frame backward.




Fold the top into its housing taking care


Alfawiki n not to crumple the plastic window,




Take the top cover out of the trunk.

Spread the cover on to the top and secure the cover with the fasteners.






Finally, insert the plastic clips into the chrome moulding.



Note: to raise the top reverse the folding procedure.



WHEELS



The dimensions of the pressed steel wheels are:

5 1/2 J x 14

Wheel removal

- Remove wheel cover and slacken wheel nuts by one turn with the wheel wrench.
- left-hand wheels: turn the nuts clockwise to unscrew
- right-hand wheels: turn the nuts counterclockwise to unscrew.



Raise the car by inserting the jack arm in the special socket in the body rocker panel.


Before operating the jack, apply the parking brake.

Fully unscrew the nuts and remove the wheel.

Reinstallation

- Tighten the nuts carefully in diagonal order. Check again tightness of nuts after lowering the jack.
 - 1 left-hand wheels: turn the nuts counterclockwise to screw in
 - right-hand Allifer Wikitwin the nuts clockwise to screw in.

TOWING




When taking a tow, secure the rope exclusively to the front suspension lower arm in correspondence of the attachment to body.

When taking another vehicle in tow, secure the rope to the axle tube making certain not to damage the pipes of hydraulic brakes.


Take A tow

Take IN tow



LUBRICATION

Routine lubrication after Coupons A and B:




MILEAGE COVERED

TICK EACH ITEM AT THE RESPECTIV

· parking brake

Grease flexible shafts & cables . Alfawiki.nl

· doors & lids



LUBRICANTS

		Commercial equivalents					
PART	Classification	AGIP	(Esso)	Shell			
Engine	SAE 20 W/40 API MS	AGIP F.1 Supermotoroil Multigrade 20 W/40	UNIFLO Motor Oil 10 W - 20 W - 40	SHELL Super Motor Oil 10 W/30			
Transmission Steering box and differential	SAE 90 API EP	AGIP F.1 Rotra Hypoid SAE 90	ESSO Gear Oil GX 90	SHELL Spirax 90 EP			
Drive shaft slip yoke	NLGI 1	AGIP F.1 Grease 15	ESSO Multipurpose Grease « H »	SHELL Retinax G			
Front wheel bearings (see maintenance schedule)	NLGI 2/3	AGIP F.1 Grease 33 FD	ESSO NORVA 275	SHELL Retinax AX			

API - American Petroleum Institute

NLGI - National Lubricating Grease Institute

SAE - Society of Automotive Engineers

ENGINE LUBRICATION	Lubrication					
	The engine is pressure lubricated by a gear pump mounted on the front cover of crankcase and driven by a shaft thru a pinion keyed to the crankshaft front end. The oil pressure is adjusted by a relief valve.					
OII level	When checking push the dipstick all the way down. Never allow the oil to fall below the minimum or, while topping up, to exceed the maximum level.					
Oil change (engine warmed up)	With the engine stopped, drain off old oil thoroughly. Remove the filter body and clean the inside of it. Replace the filter element. Replenish with new oil.					
Oil replacement after engine reconditioning	With a reconditioned engine follow the instructions given for the breaking in period. Alfawiki.nl					

The oil pressure is controlled by a relief valve in the pump body. If the pressure falls below the minimum values, an Alfa Romeo Dealer must be consulted to trace and remedy the fault.

Lubricating circuit faults are indicated by a red warning light, too.

М	ai	n	te	n	a	n	C	e

Oil pressures wit	h hot engine - psi
Engine running fast	minimum 50 maximum 65-70
Engine idling	minimum 7-14

Maintenance


To remove impurities the engine oil is filtered by a full-flow filter in series with the delivery circuit. The filter is fitted with a valve that bypasses the element if it should become clogged.

When replacing the filter element thoroughly clean the case.

It should be remembered that the periodical replacement of the element, perfect cleaning and careful assembly of the filter are essential for best engine performance.

On reassembling the filter, always replace the seal with a new one.

After refitting the filter to the engine, make sure that there are no oil leaks.



OIL FILTER


Oil flow with normal operation

Oil flow in an emergency

		IONALLY evel of coolant in engine coo	ling system reservoir		LICK			GE C		RESP	-0-
ΕV	ERY	300 miles: check tire p	ressures	6,000	9,000	12,000	15,000	18,000	21,000	24,000	000 20
	10	FRONT WHEEL BEARINGS	Adjust clearance & repack with grease								
		BOLTS AND NUTS	Tighten generally								
	1000000	BRAKE SYSTEMS	Check thoroughly								
	13	ENGINE COOLING SYST.	Change coolant (or once a year whichever comes first)								
	A	FRONT WHEELS	Adjust toe-in and check caster								
		CAR	Road and driveability test								
	16	STEERING LINKAGE	Check for play								
	15	BRAKE SYSTEMS	Change fluid (or once a year whichever comes first)								
	_	ENGINE COOLING SYST. & AIR HEATER	Inspect hoses and replace as necessary								
	-	IDLE SPEED	Check								
	14	THROTTLES	Cleaning of throats and alignment								
	13	THROTTLES & INJECTION PUMP LINKAGE	Check positioning								
	12	TANK FUEL FILTER	Change								
	11	VALVES	Check clearance and adjust as necessary								
	10	DISTRIBUTOR & TIMING	Inspect and check								
	9	SPARK PLUGS	Inspect and change as necessary								
	8	MAIN FUEL FILTER	Change element								
	Ø	AIR CLEANER ELEMENTS	Change				1				L
	6	AIR CLEANER ELEMENTS	Cleaning								
	6	VALVE TIMING CHAIN	Check tension								
	4	FAN & ALTERNATOR DRIVE BELT	Check tension								
	3	CL. & BR. RESERVOIR	Check level of fluid								
	2	BRAKE PADS	Check for wear		8						
	U	BATTERY	Check electrolyte level.	X							

62

MAINTENANCE




Alfawiki.nl

NUT TIGHTENING

Engine maintenance

Tightening torque specifications

Cylinder head nuts



Tightening sequence

Tightening torque specifications

1b-ft 52.1-53.5

55-55.7

52.1-53.5

VALVE TIMING


Engine maintenance

The V-mounted overhead valves are directly operated by two camshafts acting thru oil bath cups.

When the engine is cold, carefully measure the clearance G with a feeler gage. If the clearance is not as specified, remove camshafts and valve cups; measure the thickness S of the adjusting pad on each valve stem and replace it with another of proper thickness so that the clearance is the correct one shown in the diagram.

To facilitate this adjustment the pads are made available in a series of thicknesses ranging from .051 to .138 in. in increments of .001 in.


Valve clearance adjustment



Engine maintenance


Checking and timing

Top dead center



The valve timing is correct when:


 no. 1 piston on compression stroke, the timing mark cut in the crankshaft pulley and marked P, is in line with the reference plate and...



 ... when the timing marks cut on the camshaft front journals are in line with those on the journal bearings.

No. 1 cylinder cams must be positioned as shown in the illustration, i.e. **POINTING OUT-WARD.**

Chain tension adjustment



Proceed as follows:

- slacken off the setscrew securing the chain tensioner;
- run engine at idling speed to allow the tensioner to tighten the chain;
- lock the chain tensioner setscrew firmly.

Engine maintenance

FUEL INJECTION

Fuel is supplied to the engine by injection into the intake port of each cylinder in quantities exactly metered in accordance with the opening of throttles and RPM range.

The metering device, or « control unit », consists mainly of a barrel-shaped cam which slides automatically lengthwise as the RPM varies and rotates about its axis exactly timed with the opening of throttles.

The lift of a follower, moving closely against the cam contour, controls the delivery of the injection pump, without any lag in respect to the demand of power.

On deceleration, the fuel delivery is automatically cut off thus permitting not only to eliminate the unburned gases in a condition remarkably critical for the exhaust emission levels, but also to affect favorably the fuel consumption.

The control unit also includes suitable compensating devices which gives proper corrections for atmospheric pressure, engine and room temperature, cold starting and initial running.


The filtered air enters the engine thru four intake ports each with a throttle valve.

The idling air (throttle valves closed) is fed thru a separate circuit which, starting from the air cleaner connects to the intake ports downstream of the throttle valves and includes the idle air equalizer 12.

The accelerator pedal is mechanically linked thru the rods 9, 10 and the relay crank 8 to both the throttle valve lever and the control unit lever. Therefore, any position of the accelerator pedal corresponds to an exact position of throttle valve and control unit levers.


Description of fuel injection system

Air induction system (see the operating diagram on next page)



- 1 Fuel tank
- 2 Tank filter
- 3 Electric pump
- 4 Main filter
- 5 Injection pump
- 6 Injectors
- 7 Throttle pedal
- 8 Relay crank
- 9 Relay crank-to-control unit rod
- 10 Relay crank-to-throttle rod
- 11 Throttle valve throats
- 12 Idle air system
- 13 Air cleaner
- 14 Oil separator
- 15 Battery
- 16 Ignition switch
- 17 Pressure switch
- 18 Low fuel pressure warning light
- 19 Fuse
- 20 Liquid-vapor separator
- 21 Calibrated orifice
- 22 Injection pump oil filter
- 23 Pressure relief valve
- 24 Average seasonal temperature compensator, hand operated
- 25 Brake booster vacuum port
- 26 Air hose

Alfawiki.nl



Fuel feed system

Inserting the key in the ignition switch 16 and rotating clockwise to the first click will operate the electric pump 3. The gasoline flows from the tank 1 thru tank filter 2 and main filter 4 and feeds the injection pump 5.

The excess fuel, acting also as a coolant for the injection pump, before returning to the tank, passes thru a calibrated orifice 21 which regulates the fuel pressure within the injection pump. A pressure switch 17 inserted in the delivery pipe will switch on the warning light 18 on dashboard if a pressure drop occurs in fuel lines.

A pressure relief valve in the main filter limits the fuel pump outlet pressure bypassing fuel to the recovery pipe.

Crankcase ventilating system

The exhaust gases and the oil vapors developed during engine operation collect in the camshaft cover; from here they are sucked in the combustion chambers and burned as well as the fuel tank vapors.

The crankcase ventilating system controls gases both at high engine RPMs and at idling speed when the throttles are closed.

When the throttles are fully opened the vapors flow thru the hoses to the oil separator 14 and to the manifold chamber communicating with the intake ports.

When the throttles are partially closed, the secondary circuit comes into operation; such a circuit starts from the oil separator 14 and conveys unburned gases and vapors directly into the intake ports downstream of the throttles by means of the idle air system 12 provided with calibrated orifices. The oil collected in the separator returns to the pan via a suitable hose.


Warning

Any adjustment or servicing of the injection system must be entrusted only to an Alfa Rafacevillieraler.

FUEL INJECTION

The air cleaner is equipped with two pleated elements offering the maximum filtering surface. At the prescribed intervals disconnect the air hose, take away the air cleaner cover, withdraw the elements and clean them carefully from inside with low pressure compressed air. Moreover at the prescribed intervals change the elements.

Cleaning or replacing the air cleaner




At the prescribed periods replace the main fuel filter element. To provide room for this operation, the air cleaner must be removed as follows:

- detach two upper anchoring straps at manifold side;
- loosen at the engine side the four clamps on the intake hoses;
- disconnect the idle hoses, the vent pipe from separator, the air intake hoses and the main crankcase ventilation hose.

Alfawiki.nl

Replacing the main fuel filter element



Changing the main fuel filter element (continued) To change the main fuel filter element proceed as follows:

- disconnect the battery negative terminal and the positive starter cable;
- clean carefully the outside of filter body and nearby lines to make sure no foreign matter could enter the filter on reassembly;
- slacken the bolt securing the filter to its bracket and remove the filter:
- withdraw the filter element;
- get rid of foreign matter that may have collected in the housing and fit a new element; also replace, if damaged, the gasket between housing and baltawiki.mlthe sealing ring on bolt.

FUEL INJECTION

At the prescribed periods, replace as follows the tank filter (throw away type) located at the rear underbody of the car;

- slacken the bolt on the clamp securing the filter to the underbody;
- loosen the clamps securing the hoses to the filter inlet and outlet adapters; it is advisable to blank out temporarily the pipe from fuel tank;
- remove the filter and replace it with a new one by proceeding in reverse order of removal; take care to fit the hoses properly.

Replacing the tank fuel filter


TROUBLE	POSSIBLE CAUSE	REMEDY
Low fuel pressure warning light does not flash on when ignition key is turned.		Replace fuse. Replace bulb.
Low fuel pressure warning light stays on (fuel pump operates: a light buzzing can be heard).	Fuel tank empty. Fuel pump outlet pressure too low (warning light comes on while running at high speed).	Refuel it. Replace tank fuel filter and main filter element.
Low fuel pressure warning light stays on (fuel pump fails to operate).	Fuse in the additional fuse holder blown.	Replace fuse.
Unsatisfactory road performance.	Air induction clogged.	Check and replace air cleaner elements, if necessary.
Unsatisfactory driveability; hesitations.	Temperature setting lever improperly positioned. Fuel pump outlet pressure too low (warning light comes on while running at high speed).	Position the lever correctly. Check and replace, if necessary, tank fuel filter and or main filter element.

TROUBLE SHOOTING

If the fault cannot be traced and remedied, entrust the inspection and repair to an Alfa Romeo Dealer. Alfawiki.nl

The ignition system is of the battery and coil type with a centrifugal advance governor.

Firing order: 1 - 3 - 4 - 2



Ignition distributor

At the prescribed intervals:

Check with a feeler gage the contactbreaker point gap.

$$S = .017 - .019$$
 in.

To adjust, loosen the screws 1 and 2, insert a screwdriver in the adjustment slot 3 and pry the stationary-point plate back or forth as required.

If contacts are burned or pitted, they may be smoothed with a very fine file and then cleaned with gasoline.

Lightly smear the distributor cam with grease.

Check the inside of the distributor cap for any sign of moisture, carbon deposits or cracks. Check also the central power electrode for free movement in its seat, and that spring action is effective. At last, check the rotor arm for proper insulation and terminals on brush and cap for good operating conditions.

Checking the ignition timing

To check the ignition timing, proceed as follows:

- 1 rotate the crankshaft to bring no. 1 cylinder piston to the compression stroke, that is with both valves closed;
- 2 by slightly rotating the crankshaft, bring the advance mark F cut in the drive pulley into line with the reference plate;
- 3 remove the distributor cap and check that the contact-breaker points begin to open when the engine is turned further in its normal direction of rotation.

F P

IGNITION TIMING AT IDLE

1º/3º ATDC

A more accurate check can be made with a **stroboscopic gun** as follows:


run the engine at about 5000 rpm and direct the light from the stroboscopic gun onto the pulley: if the timing is correct, the **M** mark on the pulley will be seen in line with the reference plate.


Timing at idle speed must be adjusted with special care as it affects more greatly the emission levels.

Alfawiki.nl

IGNITION TIMING AT HIGH SPEED

31°/37 BTDC at 5000 rpm





Timing adjustment

If the timing requires adjustment, proceed as follows:

- 1 unscrew the distributor securing nut 1 on the stud so as to allow the distributor to be rotated together with its supporting clamp;
- 2 rotate the distributor body counterclockwise or clockwise according to whether it is necessary to respectively advance (A) or retard (R) the ignition setting;
- 3 retighten the nut, taking care not to move the distributor body;
- 4 recheck timing.

Timing after removal of distributor from engine When reinstalling or replacing the distributor, perform the following procedure:

- rotate the crankshaft to bring no. 1 cylinder piston to the compression stroke that is with both valves closed;
- by slightly rotating the crankshaft bring the advance mark F on pulley into line with the reference pointer;
- fit the supporting clamp onto the distributor body and tighten the clamp just snug;
- remove distributor cap and rotate the drive shaft by hand to bring the rotor arm in line with the contact for no. 1 cylinder;
- as a trial installation place the distributor on engine and move the supporting clamp so that the stud is centered in the clamp slot when the contact-breaker points are about to open for no. 1 cylinder;
- then, remove the distributor with its supporting clamp, taking care not to disturb the distributor body/clamp setting and lock the clamp in place;
- reinstall the distalfatorial adjust timing as directed above.


The spark plugs are of the surface gap type with four points and a central electrode. The only maintenance required is occasional cleaning with a brush of the central electrode and points. **No routine adjustment is necessary** of the gap between the electrode and points.

If the ceramic insulator is cracked or the electrodes are excessively worn away, the spark plugs must be replaced.

The standard plugs fitted to the engine are $LODGE\ HL$ A decal, giving the specifications for these plugs, is attached under the hood; here below, the text of the decal is repeated.


In order to comply with the Federal rule regarding the control of air pollution the engine is fitted with LODGE-HL spark plugs. These plugs are completely adequate when the automobile is driven at speeds not exceeding the limits specified by speed regulations. If the automobile is driven at sustained speeds higher than the said speed limits, LODGE-2HL spark plugs must be used.

The spark plugs should be tightened when cold to a torque of 18-25.3 lb-ft; lubricate the threads with graphite grease before fitting.



Under no condition can substitute spark plugs be used, unless they are specifically advised and approved by Alfa Romeo. Use of other plugs can promote serious engine damage, and they is a little emission levels.





Diagram

- 1 Radiator filler plug
- 2 Reservoir filler plug
- 3 Radiator drain plug
- 4 Bleed screw on pump
- 5 Drain plug on crankcase
- 6 Heater cock
- 7 Bleed screw on manifold
- 8 Reservoir
- 9 Supply line from reservoir to radiator
- 10 Thermostat
- 11 Centrifugal punAnfawiki.nl

COOLING SYSTEM

The cooling circuit is provided with a compensating reservoir containing a special **Alfa Romeo Coolant Mixture** which gives full protection against freezing down to — 22 °F.

Cooling circuit

To ensure the efficient operation of the cooling system, the following procedure should be observed.

Occasionally, check level of coolant in the reservoir: this should be done exclusively with a cold engine as with a hot engine the level may increase remarkably, even after stopping the engine.

The level of mixture in the reservoir should never fall below the " \mbox{Min} " nor exceed the " \mbox{Max} " marks.

To top up use Alfa Romeo Coolant Mixture drawn from suitable containers available by **Alfa Romeo Dealers.**

If too frequent a topping up is required, have the cooling system checked by an Alfa Romeo Dealer.

Should sudden and excessive leaks be experienced from the system, the use of fresh water is allowed provided that the specified mixture is restored and trouble remedied as soon as possible by an Alfa Romeo Dealer.

MAX

WARNING

Never remove the radiator plug unless absolutely necessary; in any case, to avoid severe injuries, wait that the liquid is cooled down to room temperature.

Every 18,000 miles (or once a year whichever comes first) have the coolant mixture renewed by an Alfa Romeo Dealer after the circuit has been flushed with a suitable descaling compound.

Changing the coolant mixture

Alfawiki.nl

IMPORTANT NOTE

The mixture in the cooling circuit gives full protection against freezing down to $-22\,\mathrm{^oF}$.

In places where the temperature falls below — $22 \, ^{\circ}$ F, the mixture can be strengthened as directed on page 31.

It is recommended that this operation be entrusted to an Alfa Romeo Dealer.


Adjusting the tension of fan, coolant pump and alternator driving belt If the tension is insufficient, the belt will slip and wear prematurely; furthermore:

the cooling action will be affected because of the reduced speed of the fan and pump;

the battery charging current will be reduced owing to the slower alternator speed.

If the tension is excessive, the alternator and pump bearings will be overloaded with the consequent risk of damage.

Therefore it is necessary to check the belt tension at the prescribed intervals.




The tension is correct when on pressing the belt down the amount of play is approximately $^{1}\!/_{2}$ in.

To tighten the belt unscrew the nut on the adjusting arm and move the alternator outwards.

Carefully retighten the nut after adjusting the belt tension.

Alfawiki.nl



The clutch is of the **automatic clearance take-up**, hydraulically-operated single-plate dry type.

The clutch pedal acts on a master cylinder supplied by the fluid reservoir 3.

When the clutch pedal is depressed the fluid under pressure actuates the piston in the cylinder 4 connected to the clutch disengagement lever 5.

The driven plate 6 is controlled by means of diaphragm spring 7.

This type of clutch has the throwout bearing constantly in contact with the diaphragm spring. Thus no more clearance exists and the wear is automatically taken up.

No regular adjustment of the play is redunwiki.nl

Operating diagram

- 1 Pedal
- 2 Master cylinder
- 3 Clutch fluid reservoir
- 4 Operating cylinder
- 5 Disengagement lever
- 6 Driven plate
- 7 Diaphragm spring
- 8 Throwout bearing
- 9 Air bleed screw

Transmission ratios


1st	3.30 : 1
2nd	1.99 : 1
3rd	1.35 : 1
4th	1.00 : 1
5th	.79 : 1
Rev.	3.01:1

The transmission has 5 synchronized forward gears and one reverse.


The gearshift lever is floor mounted.

RM = Reverse

= Synchronizer = Neutral



TRANSMISSION



Any inspection or adjustment of the transmission must be done only by an Alfa Romeo Dealer.

1 Filler plug.


Check that transmission is full of oil to the bottom edge of the filler orifice.

O Drain plug.

The drive shaft is in two sections and has an intermediate flexible support attached to the body.


The front section is provided with a rubber coupling at the transmission end; a universal joint is provided at each end of the rear section.

DRIVE SHAFT



Grease the slip yoke at the scheduled intervals ki.nl

The live axle is attached longitudinally to the supporting structure by means of two trailing arms with rubber bushes at the ends; transverse attachment is effected by means of a T-arm hinged to the body and to the rear axle thru rubber bushes. The final drive is of the hypoid type.




The front wheels are independently suspended and connected to the body by A-arms.


Coil springs and double-acting hydraulic telescopic shock absorbers are located between the lower arms and the body.

The suspension system is completed by a transverse stabilizer rod which improves the stability of the vehicle when cornering.

Upward movement of the arms is restricted by bumper pads situated near the springs. Downward movement is restricted by pads attached to the cross member.



Suspension components require no regular lubrication. Whenever the damping action of the shock absorbers is uneven, have them checked by an Alfa Romeo Dealer.




REAR SUSPENSION


Chassis maintenance

The rear suspension consists of coil springs and large diameter telescopic shock absorbers coaxial with the springs.

The suspension system is completed by a transverse stabilizer rod linked to the trailing arms and the body.



- 1 Trailing arm
- 2 T-arm
- 3 Stabilizer rod
- 4 Shock absorber
- 5 Rubber buffer and rebound strap.




The rebound of rear axle is limited upward by rubber pads and downward by fabric and rubber straps.

The suspension units do not require any regular lubrication. Whenever the damping action of the shock absorbers is uneven, have them checked by an AlfAlfowwiki.Dealer.

STEERING GEAR AND LINKAGE

This model is produced alternatively with steering of the worm and roller or recirculating ball type.



Recirculating ball steering.

At the prescribed intervals check:


- the oil level in the steering box (by
- the steering linkage joints for play.

The steering of the recirculating ball type does not require any regular adjustment.

Worm-and-roller steering.

At the prescribed intervals check:

- the oil level in the steering box (by removing the plug 1 shown in the figure);
- the steering linkage joints for play;
- the worm and roller for play (adjust with screw 2, if necessary).



The ball and socket joints of the rods do Alba William any lubrication.

Toe-in and camber

To avoid uneven and premature tire wear, and to ensure positive and stable steering, front wheel toe-in and camber must be set to the prescribed values

Toe-in and camber vary according to the car load: the values should be checked with the car standing on level ground, with full pan, tank and radiator, with the tires inflated to the prescribed pressures, with spare tire and tools and with a load corresponding to that of four persons. i.e. about 620 lbs. for Berlina and 2 persons (310 lbs) for GT Veloce and Spider Veloce.

In order to obtain the correct results these checks should be carried out by specialized mechanics using suitable equipment.

It is recommended that this operation should be entrusted to an Alfa Romeo Dealer.

Toe-in adjustment

Lock steering wheel in the central position, i.e. with the spokes symmetrically disposed in relation to the vertical; starting with the rod 1 on the steering box side, place the corresponding wheel so that the toe-in is .06 in.: measure the length thus obtained of the rod on the steering box side and shorten by .2 in. the rod 2 on the other side: bring the right-hand wheel to .06 in. toe-in by adjusting the center track rod 3:

Length of track rods

As measured between ball joint centers, the length should fall within the following limits:

1 2 10.71 \pm .3 in. **3** 21.26 \pm .4 in.

If these values cannot be restored, the cause will probably be attributable to distoAdfromwoikithme body resulting from a collision.

FRONT WHEELS

Non-adjustable; check chassis and supension arms for distortion, if necessary.


Camber


The turning circle may be adjusted by means of the screws 4 indicated in the figure below.

Turning circle

Camber
$$B = A + .20$$
" $- .04$ "

Toe-in
$$\mathbf{C} = \mathbf{D} + .12$$
"








Dual brake system

- 1 Brake pedal
- 2 Fluid reservoirs (with warning light switches)
- 3 Power cylinder
- 4 Suction port
- 5 Pistons
- 6 Friction Pads
- 7 Discs
- 8 Bleed screws
- 9 Stop light switch
- 10 Pressure regulator
- 11 Fluid level warning light





Dual brake

system

The brake unit consists of a dual power braking system.

Each one of the separate circuits, front and rear, is servo assisted and controlled by a tandem master cylinder, with one cylinder operating the front brakes and the other cylinder the rear brakes.

The friction pads of the front and rear brakes are directly actuated by the cylinders integral with the calipers.

The brakes are self-adjusting.

A valve, inserted in the rear brake circuit, regulates the pressure between front and rear brakes to provide balanced braking action.

WARNING: the pressure regulator must never be tampered with; specifically, do not attempt to act on the adjusting nut as it is factory sealed.

The stop light switch is directly operated by the brake pedal.


The two brake reservoirs have suitable markings for maximum and minimum levels; the reservoirs are provided with a baffle, which prevents

fluid from interflowing between each other; however, the reservoirs are replenished thru a single filler port common to both.

Two microswitches, located at the top of reservoirs, light up a red warning light on dashboard when the level of fluid in the reservoirs is too low; therefore, if the warning light comes on, stop the car and check the brake fluid level in the reservoirs; if the level is

too low, have the relevant circuit inspected by an authorized Dealer.

WARNING: check frequently the warning light circuit using the press-totest feature.





To maintain the brakes in good operating condition, follow the servicing instructions given below:

- Take care to prevent the minimum level of fluid in the reservoir from falling below the maximum level by more than a quarter.
- For renewal or topping up, it is absolutely essential to use only



from freshly opened sealed containers.

When adding fluid, leave the strainer in place so as to filter the fluid.

 Renew the brake fluid at the prescribed periods. For effective and reliable operation of the brake system, the pipes must always be full of fluid and free of air bubbles.

be full of fluid and free of air bubbles.

Excessive and spongy brake pedal action is an indication of the presence of air bubbles in the system.

Compressed air must not be used for replenishing the system. Should flushing of the brake circuit be required, use exclusively

fluid of the specified type.


Compressed air or alcohol must on no account be used to dry a flushed system.

Air bleeding

Bleeding should be performed with the greatest care following these instructions:

- If necessary, fill the reservoirs, thru the strainer, with the genuine fluid freshly drawn from sealed containers; during bleeding operations pay attention that fluid level does not drop below the full by more than a quarter.
- 2 Push rubber pipes over the bleed screws of a front and a rear wheel; the otlatfawikiwill lead to glass containers half full of fluid.





Loosen the bleed screws of front and rear wheel at the same time; depress the brake pedal several times allowing it to return slowly and waiting a few moments before depressing it again. This sequence must be repeated until the pipes discharge fluid free from air bubbles. Then hold the pedal down, tighten the bleed screws and remove the rubber pipes.

Repeat the bleeding procedure for the other two wheels.

If the bleeding has been carefully performed, it will be found that when the brake pedal is depressed, direct action on the fluid can be felt, free of resilience, immediately at the end of the free travel. If not, repeat the procedure.


On completion of bleeding, fill up the reservoir to maximum level, if necessary.

NOTE: being the brake system split in two circuits, the air bleeding cannot be performed by acting on the two brakes of the same circuit; in fact, the brake pedal cannot be depressed fully prevented in that by the pressure built up in the other circuits.




Friction pad inspection

At the prescribed intervals check front & rear pads for wear. Proceed as follows:



- Jack up the car and remove the wheels:
- drive the upper retaining pin out of caliper;
- remove the cross-shaped spring;
- drive out the lower retaining pin.





 Withdraw the pads with the puller
 A.2.0150.

Thickness:

new

.6 in.

wear limit .28 in. REPLACE PADS Check pad thickness.

CAUTION:

In case of uneven wear of pads, it is advisable to replace the whole set (front or read) (qwiki.nl






Clean the pad surface: never use mineral base solvents or sharp-edged tools; check that dust excluder and retaining ring are sound; if not, replace them.

Pad reassembly

Press the pistons to the bottom of cylinders with the resetting tool **A.2.0147**; do not use chance tools which could damage the pistons or the disc.






When resetting pistons care should be taken to prevent fluid overflow from the reservoir.


Positioning the pistons

Make sure the pistons are correctly positioned in the caliper by resting the template against the reference surface as shown.

A.2.0149 template for rear brakes.

A.2.0160 template for front brakes.






- 1 Template
- 2 Piston



Pad reassembly (continued)



 Insert the friction pads in the caliper; if new pads are fitted, make sure they slide freely in their housing.

 Fit a retaining pin and then the cross-shaped spring; press down the free end of spring so that the other retaining pin can be fitted.

 With a suitable drift push the retaining pins fully home and lock them in place with the safety pins.

When refitting the pads, check the conditions of cross-shaped springs and upper & lower retaining pins and replace, if necessary; however, these parts must be replaced whenever new pads are fitted.

Cleaning instructions

To clean the outside of brake assemblies use suitable detergents mixed with hot water; then thoroughly dry all components with compressed air.

Never use gasoline, trichloroethylene or similar solvents to clean the outside of brakes as these substances are detrimental to the rubber seals.

While servicing the car, be careful not to let lubricants come in contact with the discs and friction pads.


When cleaning the car, it is advisable to mask off the brakes to avoid damaging the brake components with jets of water.

Important warning

In case of accident or damage to the chassis check that the vacuum boosters are undamaged, since even slight superficial body damage may seriously impair the functioning of the brakes.

Do not coast downhill with the engine stopped; there will be no suction in the brake boosters and a greater pressure will be needed with the brake pedal to Δφετανίκος στη parable braking effect.





Parking brake operating diagram

- 1 Control lever
- 2 Operating levers
- 3 Discs
- 4 Shoes
- 5 Running clearance adjuster
- 6 Slack adjuster
- 7 Stretcher
- 8 Parking brake warning light switch




Parking brake

Parking brake linkage adjustment

The parking brake, provided with a stretcher, is mechanically-operated: the rear wheels are locked thru shoes 4 acting against a drum machined in the disc casting. Pulling the lever causes the shoes, via the operating levers 2, to expand thus locking the wheels.

A slack parking brake linkage, due to worn shoe linings, is adjusted as follows, one wheel at a time:





jack up the car and remove the wheel; fully release the brake and make sure the control cables to the calipers are slackened; act on the running clearance adjuster 5 one notch at a time in the direction shown in the figure until shoes just contact the drum, then back up the adjuster by two-three notches so that the disc rotates freely.

Gain access to the adjuster 5 with a screwdriver inserted thru one of the holes in the disc casting: if hole and adjuster are not aligned rotate the disc.

The parking brake is correctly adjusted when the wheels become locked as the lever is drawn thru half its total travel. If, after this adjustment, the linkage is yet slackened proceed as follows:

- rotate the adjuster 5 until shoes contact the drum and lock it;
- take up any slackening in the linkage by means of the slack adjuster 6;
- back up the adjuster 5 by two-three notches; in this condition the brake linkage walfewiki. Methy adjusted.



Wheel balancing


Each wheel, complete with its tire, is statically and dynamically balanced at the factory.


Whenever a tire is changed, the wheel must be rebalanced.

It should be remembered that unbalanced wheels cause unstable steering, abnormal steering gear wear and uneven tire wear.



- D Dynamic
- S Static





RECOMMENDED TIRE PRESSURE (COLD) IN PSI AT A MAXIMUM-LOADED VEHICLE WEIGHT OF 3340 LBS

Make	Front	Rear
Pirelli Cinturato SR (under all conditions)	22	23
Michelin ZX	26 (*)	26 (*)
Kleber Colombes V10	24 (*)	29 (*)

Note: For sustained speeds exceeding the limits specified by Federal regulations, inflate to the following pressures:

Michelin ZX	28 (**)	31 (**)
Kleber Colombes V10	27 (**)	31 (**)

(*) With reduced load & occasional short bursts of maximum speed.(**) With full load and continuous maximum speed.

RECOMMENDED TIRE PRESSURE (COLD) IN PSI AT A MAXIMUM-LOADED VEHICLE WEIGHT OF 3000 LBS

Make	Front	Rear
Pirelli Cinturato HR	24	26
Michelin XAS	20	24
Kleber Colombes V10GT	24	26

RECOMMENDED TIRE PRESSURE (COLD) IN PSI AT A MAXIMUM-LOADED VEHICLE WEIGHT OF 2760 LBS

Make	Front	Rear
Pirelli Cinturato HR	24	26
Michelin XAS	20	24
Kleber Colombes V10GT	Alfawiki.n24	26

TIRES



165 SR 14 tires



165 HR 14 tires



165 HR 14 tires




YES NO NO













Correct

Tire inflation pressure

The tire gives optimum performance, the tread works over its entire width, thus ensuring uniform tire wear and long life.

Too low

0

The tire will overheat: the sides of the tread will wear quickly and the tire plies will tend to separate.


Too high

Riding comfort will be reduced, and the tire will suffer from excessive wear in the center of the tread ar Alfrawika ability to knocks.




To ensure even and uniform tire wear and long tire life, front and rear wheels and the spare should be changed over regularly.

Changing over



Michelin diagram



Pirelli diagram

& INTERNALLY

EXTERNALLY

Body maintenance

Washing the car The body should be washed frequently, depending on the use of the

> the lighter is the finish paint shade the more frequent the car should be washed. Avoid washing the car in the sun and proceed as follows:

• first flush the car all over with jets of water to remove the dust; • prepare a solution of suitable detergent in water (2% in weight); • with the solution and a sponge wipe down the whole body;

car, the environmental conditions and the state of the roads. Moreover

rinse thoroughly with plenty of water;

dry with compressed air, if possible, then with chamois leather. Note: for cleaning the outside of brakes refer to page 96.

Polishing

To put fresh gloss on the paintwork, polish once or twice a year with a polish suitable for synthetic or nitrocellulose paint, according to the type of paintwork on the car.

On the chromework use gasoline to remove grease and a suitable compound to take out any scratches. Use only woollen cloth for polishing.

Do not use gasoline or solvents on rubber mouldings and weatherstrips. When refuelling or lubricating, be careful not to splash gasoline or hydraulic fluid on the paintwork.

Cleaning the windows Use only a very soft cloth or chamois leather for cleaning the windshield and windows. If the panes are very dirty, use windshield washer fluid or water mixed with alcohol.

Removing stains

Grease, oil and tar stains may be removed from the paintwork by applying gasoline to the stained area, and then rubbing it with a dry cloth. If the tar deposits have hardened, use one of the many preparations available on the market.

Upholstery Periodically dust the inside upholstery using a vacuum cleaner if possible. To remove oil and grease stains, use diluted ammonia on the cloth parts and vaseline on the leather. Use trichloroethylene or neutral soap to remove stains from the carpets. The steering whe Alfanvikintrol knobs may be cleaned with gasoline.

102

If the car will be left unused for any length of time the following protective steps should be taken:

- empty the fuel tank; clean the oil filter and the main fuel filter:
- inject a little engine oil into the cylinders thru the spark plug holes and rotate the crankshaft by hand several times in order to spread a film of oil over the cylinder walls;
- remove the battery, store it away from frost, and recharge it once a month; never allow it to become fully discharged or plate sulfation will result;
- jack up the car, clean the tires and slightly deflate them; if tires are removed, dust them internally (and their tubes) with talcum powder; store them in a dark and airy but dry place;
- dust the seats and upholstery with moth preventive;
- cover the car with a dust sheet. To avoid serious damage to the paintwork, do not use polyvinyl-type tarpaulins.

The 12-volt electrical system is wired with protected and insulated cable in order to reduce to a minimum the risk of short circuiting. The negative battery terminal is grounded.

If any instrument fails to operate or any lamp fails to light up, first check the corresponding fuses; if the fuse is sound check to ensure that the cable terminals are tight and that the bulbs are not loose or burnt out. If the trouble persists, the electrical system should be checked by a competent auto-electrician.



BATTERY

Water level

The battery water level should never be more than 3/16" above the plates and must never leave them uncovered.

When filling up the battery, use only distilled water; never add acid.

Terminals

Make sure that terminals are tight and are sufficiently coated with pure vaseline.

State of charge

The state of charge can be checked by measuring the specific gravity of the electrolyte with a suitable hydrometer.

The specific gravity/charge ratio is as follows:

```
specific gravity 

1.28 . . . . (32°Bé) = charged

1.23 . . . . (27°Bé) = half charged

1.11 - 1.14 (15° - 18°Bé) = discharged
```

If distilled water has been added to a battery, the specific gravity should not be measured until mixing is complete; to facilitate mixing, charge the battery for 30 minutes.

In climates where the temperature is nearly always above 85°F, the specific gravity of the electrolyte, when the battery is fully charged, must be lower that the lower that the ligure, viz. 1.21 (25°Bé).

The alternator requires some special cares.

- It should not be tampered with.
- Never disconnect the battery terminal of alternator-to-battery cable while the engine is running.
- When recharging the battery, completely disconnect it from the system.
- When electric weldings are carried out on car, disconnect battery making sure the positive terminal is properly insulated.
- Never reverse the battery polarity or the diodes will be damaged.
- To avoid overloading the bearings, check frequently the belt for proper tension.
- It is recommended to entrust any inspection or repair work to Alfa Romeo Dealers.

Regularly:

Inspect commutator and brushes.

The brushes must be clean and must slide freely in their holders: brush working face must be cleaned with a cloth soaked with gasoline; the brush spring must apply effective pressure.

When one brush has to be replaced, it is a good rule to replace the other at the same time. Always fit new original brushes of the prescribed type.


After replacing the brushes, run the starter with no load and for such time as is necessary to bed the brush working face to the commutator.

If the commutator is burned or elongated, it must be reworked on a lathe taking care to decrease the diameter of the minimum required only: after machining, undercut the mica between the segments.

Alternator

Starter

Replacing a lamp




Headlamps

Fog lamps (Berlina & GT Veloce)

Remove the rim by pulling it off from the bottom (on Spider Veloce first loosen the screw at the lower edge of rim).

Slacken the three screws on the lens retaining ring and remove the ring.



Rotate the lens unit counterclockwise and withdraw it.

Disconnect the wire junction.


Replacing a bulb


Parking & stop lights.

Direction indicators & Emergency flashers.


Back-up & license plate lights.

Loosen the attaching screws and remove the lens.






Push in the bulb and rotate counter-clockwise...





Side marker lights

At the front, gain access to the marker lights from the bottom of fenders by removing the access port cover; at the rear, from the inside of trunk. Take out the lamp holder and withdraw the bulb.



Courtesy lights


Remove the lens of dome light by loosening the screw at the side and free the bulb from the clips.

On **Spider Veloce** the light is in the rearview mirror: withdraw the lens from mirror body and remove the bulb.


Glove box light (Spider only)
Trunk light (Berlina only)
Engine compartment light.

Free the bulb from the clips.

HEADLAMP BEAM SETTING









To set the headlamp beam, act properly on the adjusting screws shown in the illustration.

V Vertical adjustment

H Horizontal adjustment

Alfawiki.nl

In the trunk there are:

Spare tire under the mat



Jack



- Tool kit, containing:
- Tommy bar for plug spanner
- Box spanner for plugs
- Pliers
- Screwdriver
- Phillips screwdriver
- Wheel brace





WIRING DIAGRAMS

Alfawiki.nl

1750 BERLINA

2 Coi 3 Igni 4 Sta 5 Alte 6 Vol	gnition distributor Marelli S.103B starter Bosch EF(R)12V0,7PS liternator Bosch K1(R,L)14V35A20 foltage regulator Bosch AD1/14V	46 47	Engine compartment light Courtesy light (microswitch on door jambs) Courtesy light (toggle switch in light unit) Trunk light switch			
6 Vol: 7 Wirn 8 Hore 9 Buz 10 Fue 11 Fus 12 Jun 13 Add 14 Hore 15 Cod 16 Oil 17 Lov 18 Col 19 Mid 20 Fue 21 Lov 22 Flas 23 Blo 24 Cig 25 Ele 26 Fog 27 Hea 29 Bra 30 Inst 31 Dire 33 Buz 34 Sto 35 Bad 36 Wir	rage regulator dshield wiper (2 ns zer level sender ebox ction boxes and little little level sender ebox ction boxes and little	Bosch AD1/14V 2 speed) Bosch WS4902AR5A(0) I connectors der er sender eender warning light switch e solenoid d warning light switch w relay w warning light switches king lights, headlamps	50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 71 72 73 CA A B B G G	white yellow	p light . dicators lers	ght light light
40 Wir 41 Flu 42 Em 43 Hea	Windshield wiper Fluid level warning light testing Emergency flashers and warning light Heated rear window Parking brake warning light		M /	R grey A brown e figure following agram shows the w		et code on the


PLATE ON FUSEBOX


1, 2, 3 Main devices 4, 5 Parking lights

6 Indicating devices

7 L.H. high beam


8 R.H. hig beam 9 L.H. low beam 10 R.H. low beam





1750 GT VELOCE®


2 Coil Bosch K12V 3 Ignition distributor Marelli S.103B 4 Starter Bosch EF(R)12V0,7PS	45 Engine compartment light 46 Courtesy light (microswitch on door jambs) 47 Courtesy light (toggle switch in light unit) BULBS						
	48 Headlamp hi/low sealed beam 49 Fog lamp						
8 Horns	50 Rear parking & Stop lights 5/21 watts						
10 Fuel level sender11 Fusebox12 Junction boxes and connectors13 Additional fuse holder	 51 Front direction indicators and emergency flashers. 52 Rear direction indicators and emergency flashers. 53 Back-up lights. 						
14 Horn relay 15 Coolant thermometer sender	54 Front parking lights 5 watts 55 License plate lights						
16 Oil pressure gage sender17 Low oil pressure warning light switch	56 Side marker lights 4 watts						
18 Cold starting device solenoid19 Microswitch	57 Engine compartment light / 5 watts 58 Courtesy lights						
 20 Fuel cut off solenoid 21 Low fuel pressure warning light switch 22 Flasher unit 23 Blower motor 24 Cigarette lighter 	59 Instrument lights60 Fuel reserve warning light61 Blower warning light62 Alternator warning light .						
25 Fuel pump	63 Direction indicator warning						
26 Fog lamp relay 27 Heated rear window relay	light 64 Low oil pressure warning						
28 Heated rear window	light						
29 Brake fluid level warning light switchesSWITCHES30 Parking and instrument lights, headlamps	65 High beam warning light . 66 Parking light warning 67 Low fuel pressure warning iight						
and flashing 31 Direction indicator	68 Parking light warning 69 Brake warning light						
32 Horn control 33 Buzzer	70 Emergency flashers warning light 71 Heated window warning light						
34 Stop light 35 Back-up light							
36 Windshield washer, foot operated 37 Ignition and starting 38 Blower 39 Fog lamp 40 Windshield wiper 41 Fluid level warning light testing	CABLE COLOR CODE AZ blue NE black BI white RO pink GI yellow RS red GR grey VE green MA brown VI violet						
42 Emergency flashers and warning light43 Heated rear window44 Parking brake warning light	The figure following the color code on the diagram shows the wire gage in mm ² .						
PLATE ON FUSEBOX 1 2 3 4 5 6 7 8 9 10							
1, 2, 3 Main devices	ZI LUCI CITTÀ ALIMEN. XBB. ABB. ANABB. ANABB.						
4, 5 Parking lights VARI	indio. Comoras Largina Lamasias Lamasias						




- 4, 5 Parking lights
 6 Indicating devices
 7 L.H. high beam

- 8 R.H. high beam
- 9 L.H. low beam
- 10 R.H. low beam
- 114

110





Alfawiki.nl

1750 SPIDER VELOCE

1 Battery 12 V-60 Ah	BULBS			
2 Coil Bosch K12V				
3 Ignition distributor Marelli S.103B	45 Headlamp hi/low sealed beam			
4 Starter Bosch EF(R)12V0,7PS	46 Parking & Stop lights 5/21 watts			
5 Alternator Bosch K1(R,L)14V35A20	47 Front direction indicators			
6 Voltage regulator Bosch AD1/14V	and emergency flashers .			
7 Windshield wiper (2 speed)	48 Rear direction indicators 21 watts			
Bosch WS4904AR2A(0)	and emergency flashers .			
8 Horns	49 Back-up lights			
9 Buzzer	50 Front parking lights 5 watts			
10 Fuel level sender 11 Fusebox	51 License plate lights Swatts			
12 Junction boxes and connectors	To Old Luckton Awatto			
13 Additional fuse holder	52 Side marker lights 4 watts			
14 Horn relay	53 Engine compartment light .)			
15 Coolant thermometer sender	54 Coutesy light 5 watts			
16 Oil pressure gage sender	55 Glove box light			
17 Low oil pressure warning light switch	56 Ash tray light 3 watts			
18 Cold starting device solenoid	57 Instrument lights			
19 Microswitch 20 Fuel cut off solenoid	58 Alternator warning light .			
21 Low fuel pressure warning light switch	59 Blower warning light			
22 Flasher unit	60 Fuel reserve warning light			
23 Blower motor	61 Direction indicator warn-			
24 Cigarette lighter	ing light			
25 Electric fuel pump	62 Low fuel pressure warning			
26 Brake fluid level warning light switches	light			
	63 Low oil pressure and park-			
SWITCHES	ing brake warning light . 64 Parking light warning			
27 Parking lights, headlamps and flashing	65 High beam warning light.			
28 Direction indicator	66 Brake warning light			
29 Horn controi				
30 Buzzer	67 Emergency flashers warn- ing light			
31 Stop light	ing light			
32 Back-up light				
33 Windshield washer, foot operated34 Ignition and starting	CARLE COLOR CORE			
35 Dashboard light	CABLE COLOR CODE			
36 Blower	AZ blue NE black			
37 Windshield wiper	BI white RO pink			
38 Emergency flashers and warning light	GI yellow RS red			
39 Parking brake warning light	GR grey VE green			
40 Engine compartment light	MA brown VI violet			
41 Courtesy light (microswitch on door jambs)				

PLATE ON FUSEBOX

43 Glove box light

42 Courtesy light (toggle switch in light unit)

44 Fluid level warning light testing

1, 2, 3 Main devices

4, 5 Parking lights

6 Indicating devices


116


7 L.H. high beam 8 R.H. high beam 9 L.H. low beam 10 R.H. low beam



The figure following the color code on the

diagram shows the wire gage in mm2.





Alfa Romeo

Via Gattamelata, 45 - 20149 MILANO

DIASS - Pubblic. N. 1572-R1 4/71 - 1000

> Printed in Italy arti grafiche milanesi

Stampato su carta patinata Burgo da gr. 200 e 96 al mq.

All rights reserved. This book, or parts Alfawiki nl thereof, may not be reproduced in any form without permission of Alfa Romeo S.p.A.